

INSTRUCTION MANUAL

CANVASLITE SUNROOM



CANVASLITE SUNROOM

CANVAS SERIES

COMPATIBILITY

Airforce 1^{V1/V2}, Jet Force, Titan, Atlas, Millbrook (2010 onwards), Sheraton, Duxton, Mission Control








ON A ZEMPIRE® POLE CANVAS TENT









KEY TIPS



When connecting the sunroom walls, unpeg the front of the awning before you attach it. Then re-peg after attaching as this will allow the walls to easily zip and give you a flat panel once complete.



If you experience heavy rain or morning dew, flick the inside of the cover a few times to remove water from the mesh panel before opening the cover.



Do not over tension guy ropes as your tent is designed to be free standing without the need for these. The guy ropes should be taught but shouldn't pull your tent out of shape.



For quick and easy pack away, stack all wall panels on each other and fold at the same time.



Internal window panels can be half opened to control airflow and privacy. Fold window panels so they sit between the lower cover and mesh panel.



Place the floor panel in the carry bag first, as it will act as a slide to help insert the wall panels into the bag easier.



HALO LOUNGER

Built for the sleepy camper with an infinite recline, suspended seat and sliding pillow. It is sturdy and comfortable for lazy summer days.



KITPAC ROUND^{V2}

A large round camping table with an attractive and durable bamboo tabletop. Folds down small, storing inside a compact carry bag.



ROCO LOW RIDER^{V2}

Perfect for camping, picnics and outdoor festivals. Its modern design makes it equally suited to the campsite as it is at home on your deck.



ECO CUPBOARDS

The adjustable height and wide bamboo tabletop makes this adaptable twin cupboard perfect for bedroom, living or kitchen storage.

PITCHING INSTRUCTIONS

1. Unpacking

When you take your sunroom out for the first time, take a moment to see how it is packed or take a photo with your phone. This will help you when it comes to packing it away. Separate and identify the different parts included with your sunroom. The package should include the following:

- 2 x side panels
- 1x front panel (with a door)
- 13 x Dome Peas 6mm
- 1x PE floor insert
- Pole spacer set

2. Loosen Guy Ropes

Before attaching the sunroom, loosen the guy ropes on your tent awning to remove tension on the panels. Check that the webbing guide straps on the awning are taught and square to ensure correct peg placement.

3. Side Panels Come First

The side panels should be attached first (the logo on the outside of the panel indicates the side closest to the front of the awning). Starting with the tent side of the panel, attach using the velcro on the inside edge of the tent awning. The extended storm skirt should be folded inside the awning.

Once the panel is connected, attach the support tag over the central awning pole and adjust tension as needed.

Repeat with the opposite side panel.



4. Front Panel

When attaching the front panel, first attach the support tag over the central awning pole.

When connecting the velcro on the front panel, begin in the centre and work your way outwards towards the sides. This will ensure that the panel aligns correctly with the awning.

5. Storm Skirts

The lower storm skirt should be folded inwards and the awning poles should rest on top of the skirt

Attach the storm skirt to the velcro sewn onto the bottom seam of the awning valance.

6. Pegging

Peg out the walls, being careful not to over-tension. You may also need to adjust the placement of the awning valance pegs to properly tension the sunroom. You can now re-tension the awning guy ropes.

7. PE Floor

If you wish to use the PE floor insert, this should be laid on top of the storm skirt in order to seal out the weather

NOTE: As ZEMPIRE® sunrooms are universal, the floors are designed to fit our largest tents. If you find that your floor is too wide, you may decide to trim off the excess material.

8. Awning Poles

Place the awning poles and tent eve poles on top of the floor to keep it in place.

9. Spacer Set

Your sunroom comes with a spacer set. These spacers are designed to go in-between the side awning pole sections to increase their length. This allows them to be angled outwards to match the side of the tent, creating more useable space inside your sunroom.

10. Pack Away

- When packing away your Canvaslite Sunroom check the outside of the walls to be sure that the canvas is clean (remove any bird droppings etc) and is totally dry before taking down.
- Windows and doors should all be zipped fully closed.
- Remove, clean and pack the pegs in provided storage bag.
- Remove the front wall and lay flat on the ground. Remove both side walls and lay over the front wall.
- Fold the front wall to the same shape as the side walls (fold over the top portion of the front wall).
- Fold the sunroom lengthways to 2/3rds the width of the storage bag.
- Fold the sunroom to a suitable length to fit comfortably inside the carry bag.
- Store with tent in a clean and dry environment.

Condensation

It is important that lower vents are opened at all times to reduce the risk of condensation. During humid or damp conditions, it is recommended that the window covers are opened to expose the mesh layer, enabling additional airflow throughout your tent.

Do not use foam swabs or non-bonded mats directly on the tent floor. This will cause condensation between the mat and floor and if not dried out, can lead to mildew forming.

WEATHERING YOUR TENT AND SUNROOM

When you first get your new tent, you will need to weather it. This is a process of soaking the fabric to ensure the cotton threads swell up, reducing stitch holes and creating a watertight surface.

When you pitch your tent for the first time, wet the tent with a garden hose until the fabric is visibly damp. Allow to dry and repeat two or three times.

Your tent will get more watertight the more you use it. Do not be concerned if you have a small amount of water coming through the seams on the first few times you get heavy rain.

Natural Fibre

Our ZEMPIRE® Canvas material is a combination of cotton (for breathability and water fastness) and polyester (for strength). You may notice variations of both colour and thread thickness. This is completely normal with a natural breathable fibre.

Fire Retardant

ZEMPIRE® Canvas Tents are naturally fire retardant. While this significantly reduces the risk of the fabric catching on fire, it is by no means fire-proof. Ensure open flames are kept well away from your tent at all times.

For a detailed description of all the features and specifications please visit our website.

CARE INSTRUCTIONS

- Ensure guy ropes are out at all times during use.
- 2. Make sure you have all vents open at all times. Constant airflow will drastically reduce condensation in humid weather conditions. Never cook in your tent as it is unsafe and would also heavily increase condensation.
- 3. Ensure all doors are zipped closed before fitting and removal. This helps keep the panel's shape and prevents stress on panels/zips.
- 4. Never pack your sunroom away wet. If you must take your sunroom down when wet, ensure that it is dried completely as soon as possible to prevent mildew forming.
- 5. If mildew does form on your sunroom, wash off with warm water and a soft brush to prevent further growth. Do not use soap or detergents.
- 6. Do not use aerosol spray cans or an open flame inside your tent.
- 7. Always use a peg puller to remove pegs. Never remove pegs by pulling the sunroom or peg loops; always clean and dry pegs before storing.
- 8. This tent is not designed to withstand storm conditions. During a severe storm, it is recommended that the tent be taken down.
- 9. Do not leave your tent pitched unnecessarily for extended periods of time. UV light damages the fly and will shorten the life of your tent.

NEED HELP WITH YOUR SUNROOM?

We have a range of videos on our website which can help you.

Follow the QR code or type the link below in your browser. We suggest to check out our videos beforehand in case you don't have service at your holiday destination.





ZEMPIRECAMPING.INFO/VIDEO-GALLERY

5 Year Limited Warranty

Please take time to read about the protection we offer you.

All our products come with a guarantee designed to protect you as our valued customer. Zempire® Camping Equipment will repair or replace this product, at their discretion, should it fail due to faulty materials or manufacture for a period of 5 years from the date of purchase.

The Guarantee is subject to the following conditions:

- 1. The Guarantee only applies to an original purchaser who purchased this product in an unopened condition from an approved retail outlet.
- 2. The Guarantee does not apply if the product has been used for anything other than reasonable personal use. Commercial use (e.g. rental) or continuous use are expressly excluded.
- 3. Damage due to normal wear and tear, accident, acts of God, negligence (other than by Zempire® Camping Equipment), failure by the purchaser to ensure instructions for setting up and care are observed, deterioration due to abnormal exposure to ultraviolet light, damage from wind, insects, animals or mold/mildew, or any other cause reasonably beyond the control of Zempire® Camping Equipment are not covered.
- 4. If redress is sought under the terms of this Guarantee, then the product must be returned by the purchaser to the outlet from where it was purchased within the Guarantee period, in a clean, dry state and with proof of purchase.
- 5. All transport costs and any other indirect costs are excluded from the Guarantee.
- 6. Zempire® Camping Equipment reserves the right to make a reasonable charge for repairs which it determines are not within the scope of the Guarantee.
- 7. The Guarantee does not limit, modify or exclude any rights under any law if doing so would contravene that law or make any part of this Guarantee invalid. However, Zempire® Camping Equipment:
 - a) excludes (to the extent permitted by applicable law) all conditions and warranties that might otherwise be implied; and
 - b) limits its liability for breach of any such condition or Guarantee that it cannot exclude together with its liability under the Guarantee, to repairing or replacing the Goods or paying the cost of having the Goods repaired or replaced (at Zempire® Camping Equipment's option).

Australia Only

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

USA Only

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Europe Only

The consumer has legal rights under applicable national legislation governing the sale of consumer goods and those rights are not affected by the guarantee.

All warranty claim processes are explained on our Zempire® website. Please go to **www.zempire.co.nz**, select your location and follow the instructions to lodge a warranty claim.

International Distributors:

New Zealand & Australia

Zempire® Camping Equipment 6 Karewa Place, Pukete, Hamilton, 3200, New Zealand Ph: +64 7 848 1610

United Kingdom, Belgium, Netherlands & Luxembourg

Outdoor & Sports Company Ltd. Redfern House, Dawson Street Hyde, Cheshire, SK14 1RD, UK Ph: +44 161 366 5020

North America

Outdoor & Sports Company Inc. 610 Alden Road Unit 101 Markham, ON, L3R 9Z1, Canada Ph: +1 905 940 9511

Germany, Austria, & Switzerland

Sport-tech Goldbeckstrasse 6 69493 Hirschberg, Germany Ph: +49 6201 8439710

South Korea

Coldspin Corporation 20 Gurodong-ro 15-gil Guro-gu, Seoul, South Korea Ph: +82 2 3397 7711

Designed and tested in New Zealand. Made with care in China.



AS PART OF OUR ZEMPIRE FAMILY, SHARE YOUR CAMPING MOMENTS ON SOCIAL





